

Austauschanleitung für den Elektrofachmann
Service manual for an authorized electrician

Wechsel WHT alt gegen neu

Exchange WHT old to new



de > 2

en > 3



1 Sicherheitshinweise



Diese Austauschanleitung ist in Verbindung mit der jeweils gültigen Gebrauchs- und Montageanleitung zu verwenden! Sie setzt qualifiziertes Fachwissen voraus und gibt zusätzliche Hinweise für die Reparatur, die nur durch einen autorisierten Elektrofachhandwerker unter Berücksichtigung der geltenden Normen und Vorschriften ausgeführt werden darf.

Elektronische und elektrische Bauteile dürfen nicht mit Feuchtigkeit in Berührung kommen. Sollten es dennoch dazu gekommen sein, darf das Gerät nicht in Betrieb genommen werden. Bitte nehmen Sie dann Kontakt mit unserem Werkskundendienst auf.

2 Austausch des WHT

2.1 Gerät vom elektrischen Netz trennen / Spannungsfreiheit am Gerät sicherstellen!

<p>Bei Geräten mit Unterputzsteckdose</p> <p>1. Schrauben der Abdeckplatte lösen, Abdeckplatte entfernen, Gerät nach oben schieben, Stecker ziehen, Gerät entfernen.</p>	<p>Bei Geräten mit Festanschluss</p> <p>1. Schrauben der Abdeckplatte lösen, Gerät nach oben schieben, Kabelfixierung und Lüsterklemme lösen, Gerät entfernen, Abdeckplatte entfernen.</p>	<p>2. Alten Wandhalter abschrauben, neuen Wandhalter an gleicher Position befestigen, Unterputzsteckdose entfernen (falls vorhanden).</p>
<p>3. Anschlussleitung des neuen WHT gemäß der Installationsbedingungen kürzen oder ggf. entfernen.</p>	<p>4. Neuen WHT gemäß Bedienungsanleitung mittels Festanschluss anschließen. Fehlende Mantelisolierung muss ergänzt werden!</p>	<p>5. Gerät von oben auf den Wandhalter aufrasten und Luftansauggitter befestigen.</p>

Hinweis: Unter dem WHT muss Sensorabstand von 35 cm zu Schränken oder anderen Oberflächen eingehalten werden.

1 Safety notes



Important note: This service manual should be used together with the current version of operating and installation instructions. It requires qualified technical knowledge and offers support for the maintenance and repair by an authorised electrician only! Due to the process of continuous improvement, CLAGE reserves the right to change details mentioned in this manual without notice.

Electronic and electrical components must not get wet at all. If there is any indication that the appliance came in contact with wetness, it is not allowed to put the appliance into operation. In this case please contact our after sales service department.

2 Replacement of the WHT

2.1 Disconnect the appliance from the power supply!

<p>Appliances with flush mounted socket</p> <p>1. Unscrew and remove the cover plate, move the appliance upwards, pull the plug, remove the appliance.</p>	<p>Appliances with direct connection</p> <p>1. Unscrew the screws of the cover plate, move the appliance upwards, loosen the cable retention and terminal strip, remove the appliance, remove the cover plate.</p>	<p>2. Remove the old wall bracket, mount the new wall bracket at the same position, remove the flush mounted socket (if available).</p>
<p>3. Shorten or remove the connecting cable of the new WHT according to the installation conditions.</p>	<p>4. Connect the new WHT by a direct connection according to the operation instructions. Missing sheath insulation must be replaced</p>	<p>5. Snap on the appliance from above on the wall bracket and attach the air intake grille.</p>

Note: There must be maintained a sensor distance of 35 cm to cabinets and other surfaces under the WHT.

CLAGE GmbH

Werkskundendienst

Pirolweg 1–5
21337 Lüneburg
Deutschland

Fon: +49 4131 8901-40
Fax: +49 4131 8901-41
E-Mail: service@clage.de



CLAGE GmbH

After-Sales Service

Pirolweg 1–5
21337 Lüneburg
Germany

Phone: +49 4131 8901-40
Fax: +49 4131 8901-41
Email: service@clage.de